

# CNC MILLING SPINDLE KIT

2200W (3.0HP) / MAX. 6000RPM,  
(BRUSHLESS MOTOR AND DRIVER, 220VAC)

---



## Panel Control Parameter Settings

FN000 = D0012

FN001 = 1

FN010 = 36

---


## Analog Control Parameter Settings

FN000 = D0012

FN001 = 1

FN010 = 36

FN220 = 520 (0-10v)  
1040 (0-5v)




\*Must restart after setting

# CNC MILLING SPINDLE KIT

2200W (3.0HP) / MAX. 6000RPM,  
(BRUSHLESS MOTOR AND DRIVER, 220VAC)

## Wiring Diagram



# CNC MILLING SPINDLE KIT

2200W (3.0HP) / MAX. 6000RPM,  
(BRUSHLESS MOTOR AND DRIVER, 220VAC)

---

## Notes

Pressing MODE at anytime brings you to parameter options.

R & T is jumped together  
One leg of 220v is assigned to R  
Other leg of 220v is assigned to S

U, V, W are assigned to spindle power output.  
U, V, W are interchangeable.

If spindle starts counter-clockwise when it should be turning clockwise, swap U & V.

### Under Panel Control Setting

Pressing Shift/Run button - Starts motor

Pressing Set/Stop button - Stops motor