




NOTE: If spindle spins in reverse, please swap U & V.