




X Axis



Y Axis



Z Axis



Tolerances - mm
 .xxx = +/- .0254
 xx = +/- .127
 x = +/- .254
 . = +/- .508